

**XVIIIth EUROPEAN CONGRESS
ON MOLECULAR SPECTROSCOPY**

ABSTRACTS

PICOSECOND CARS STUDY OF PHONON ENERGY RELAXATION IN IONIC CRYSTALS

L. Angeloni, B. Castellucci, F. Fieschi, A. Razzini
 Dep. of Chemistry, University of Florence, Italy

Vibrational relaxation is measured in ionic crystals at various temperatures by picosecond CARS spectroscopy. Crystals studied were CaCO_3 .

As far as CaCO_3 is concerned, the coherent decay of the phonons at $440, 617, 930, 1184$ and 1140 cm^{-1} showed different behaviours with temperature.

The decay time of the 440 cm^{-1} mode ranges from 11 ps at 10 K to 1 ps at 100 K showing a quadratic dependence of the inverse of the decay time with temperature. The decay of the phonon at 617 cm^{-1} can be detected only at low temperature with a lifetime of about 1 ps at 10 K . The phonon at 930 cm^{-1} shows instead a longer decay time which can be measured in the range of temperature from 10 K to 100 ps to room temperature 1 ps . In this case the dependence of the inverse lifetime with temperature is linear above 40 K being almost temperature independent below this temperature.

The decay of the 1184 cm^{-1} totally symmetric vibration mode of CaCO_3 has been measured to be 11 ps at 10 K .

This result compares well with the lifetime value reported by Leubner and Kaiser, i.e. 1 ps at 8 K .